


### A、 Precautions

Note: before installation, make sure that the power supply has been disconnected, and be careful of electric shock!

- 1 . Carefully open the package and place the parts.
- 2 . According to the requirements of watt mark on the lamp head, install a bulb (not included) with the maximum wattage, and finally turn on the power switch.
- 3 . If the wire of the lamp is damaged, the wire shall be replaced by the manufacturer's service agent or qualified person to avoid danger.



4 . This lamp can only be used in non humid room with a maximum rated temperature of 30 °C.

5 . The minimum distance between the light source and the object is 0.8m.

6 . Cleaning of lamps (please disconnect the power supply)

- 1) . Please use a soft cloth to wipe the dust on the lamp body
- 2) . Please use neutral solvent to clean the glass and do not use abrasive paper and wire brush to clean the lamp.

### B、 Installation procedure

- 1 . Cut off the power supply and wear gloves before assembling the lamp
- 2 . Connect the lamp body wire with the external wire with the terminal (3), l for the fire wire, n for the neutral wire, and the ground wire
- 3 . Fix the aluminum part (4) on the aluminum part (2)
- 4 . Fix the aluminum part (6) on the aluminum part (5)

